


# AXIS F4005 Dome Sensor Unit

## Installation Guide







1x



4x




1x



1x





1x






1x

## AXIS F4005 Dome Sensor Unit


---









**1.1**




**1.2**







## 2.1



## 2.2




## 2.3







**3.1**




**3.2**



## 3.3




## 3.4





**3.5**

**4x**



**3.6**







Installation Guide

AXIS F4005 Dome Sensor Unit

© Axis Communications AB, 2016

Ver. M1.3

Date: February 2016

Part No. 1562035