

# LKNX-300 KNX Interface

## Installation instructions

Instructions de montage


Montageanweisung



Montagevoorschrift

Istruzioni di montaggio


Instrucciones de montaje

Monteringsanvisning







Connectors		
EXT	1	Input GND
	2	Input B
	3	Input A
KNX TP1	4	Input -
	5	Input +



2 poles: Weidmüller BLZP 5.08/02/180

4.5 lb-in/0.5 Nm


0.2 - 2.5 mm<sup>2</sup>




3 poles: Weidmüller BLZP 5.08/03/180

4.5 lb-in/0.5 Nm

0.2 - 2.5 mm<sup>2</sup>





35 mm x 7.5 mm DIN rail (EN 50022, BS 5584, DIN 46277-3)

